



Contents

00 - Technical data	1
1 Identification	1
1.1 Engine number/engine data	2
2 General notes	3
2.1 Rules for cleanliness when working on the auxiliary/supplementary heater and the fuel system	3
2.2 General notes on self-diagnosis	3
2.3 General notes on ignition system	3
3 Safety precautions	5
3.1 Safety precautions when working on the fuel supply system	5
3.2 Safety precautions when working on the cooling system	6
3.3 Safety precautions when using testers and measuring instruments during a road test	6
3.4 Safety precautions when working on the exhaust system	6
3.5 Safety precautions when working on the subframe	7
3.6 Safety precautions when working on the ignition system	7
4 Repair instructions	9
4.1 General notes	9
4.2 Bolts/nuts	9
4.3 Identification plates	10
4.4 Use of impact wrenches	10
4.5 Foreign particles in engine	10
4.6 Contact corrosion	10
4.7 Routing and attachment of pipes, hoses and wiring	11
4.8 Installing radiators and condensers	11
4.9 Checking vacuum system	11
5 Technical data	13
5.1 Technical data of injection system	13
10 - Removing and installing engine	14
1 Removing and installing engine	14
1.1 Removing engine	14
1.2 Separating engine and gearbox	34
1.3 Securing engine to engine and gearbox support	41
1.4 Installing engine	45
2 Assembly mountings	53
2.1 Exploded view - assembly mountings	53
2.2 Removing and installing engine mountings	54
3 Engine cover panel	64
3.1 Removing and installing engine cover panel	64
13 - Crankshaft group	65
1 Cylinder block (pulley end)	65
1.1 Exploded view - poly V-belt drive	65
1.2 Removing and installing poly V-belt	67
1.3 Removing and installing poly V-belt tensioner	68
1.4 Removing and installing vibration damper	68
1.5 Removing and installing bracket for ancillaries	69
1.6 Renewing crankshaft oil seal (pulley end)	69
2 Cylinder block (gearbox end)	72
2.1 Exploded view - drive plate	72
2.2 Removing and installing drive plate	72
2.3 Renewing crankshaft oil seal (gearbox end)	73



3	Crankshaft	76
3.1	Exploded view - crankshaft	76
3.2	Allocation of main bearing shells	79
3.3	Crankshaft dimensions	81
3.4	Measuring axial clearance of crankshaft	81
3.5	Measuring radial clearance of crankshaft	82
4	Auxiliary drive	83
4.1	Exploded view - auxiliary drive	83
4.2	Removing and installing spur gear drive	84
4.3	Renewing oil seal for power steering pump drive	87
4.4	Renewing oil seal for AC compressor drive	88
5	Pistons and conrods	91
5.1	Exploded view - pistons and conrods	91
5.2	Removing and installing pistons	93
5.3	Checking pistons and cylinder bores	94
5.4	Checking radial clearance of conrod bearings	95
15	- Cylinder head, valve gear	97
1	Cylinder head	97
1.1	Exploded view - cylinder head	97
1.2	Removing and installing cylinder head	99
1.3	Removing and installing cylinder head cover	105
1.4	Checking compression	107
2	Timing chain cover	110
2.1	Exploded view - timing chain cover	110
2.2	Removing and installing timing chain cover (left-side)	112
2.3	Removing and installing timing chain cover (right-side)	115
2.4	Removing and installing timing chain cover (bottom)	117
3	Chain drive	122
3.1	Exploded view - camshaft timing chains	122
3.2	Exploded view - drive chain for valve gear	125
3.3	Exploded view - drive chain for auxiliary drives	127
3.4	Removing and installing camshaft timing chain	127
3.5	Removing camshaft timing chain from camshafts	129
3.6	Removing and installing drive chain for valve gear	137
3.7	Removing and installing drive chain for auxiliary drive	138
4	Valve gear	140
4.1	Exploded view - valve gear	140
4.2	Measuring axial clearance of camshaft	143
4.3	Measuring radial clearance of camshaft	143
4.4	Removing and installing camshaft	144
4.5	Checking hydraulic compensation elements	153
4.6	Removing and installing valve stem oil seals	155
5	Inlet and exhaust valves	163
5.1	Valve dimensions	163
5.2	Checking valve guides	163
5.3	Checking valves	164
17	- Lubrication	165
1	Sump/oil pump	165
1.1	Exploded view - sump/oil pump	165
1.2	Exploded view - sump (top section)	168
1.3	Engine oil	169
1.4	Removing and installing sump (bottom section)	169
1.5	Removing and installing sump (top section)	171



1.6	Removing and installing oil pump	175
1.7	Removing and installing oil level and oil temperature sender G266	176
1.8	Checking oil level	177
2	Engine oil cooler	178
2.1	Exploded view - engine oil cooler	178
2.2	Removing and installing engine oil cooler	179
2.3	Removing and installing engine oil cooler (front)	181
3	Crankcase breather	183
3.1	Removing and installing hose for crankcase breather system	183
4	Oil filter/oil pressure switches	184
4.1	Exploded view - oil filter housing/oil pressure switches	184
4.2	Removing and installing oil temperature sender G8	185
4.3	Checking oil pressure switch F22 / oil pressure switch for reduced oil pressure F378	186
4.4	Removing and installing oil pressure switch F22	186
4.5	Removing and installing oil pressure switch for reduced oil pressure F378	187
4.6	Removing and installing valve for oil pressure control N428	188
4.7	Checking oil pressure	188
4.8	Removing and installing oil filter housing	189
5	Oil circuit	191
5.1	Exploded view - oil spray jets/valves	191
5.2	Removing and installing oil spray jets/valves	192
19	Cooling	194
1	Cooling system/coolant	194
1.1	Connection diagram - coolant hoses	194
1.2	Draining and filling cooling system	196
1.3	Checking cooling system for leaks	202
2	Coolant pump/thermostat assembly	205
2.1	Exploded view - coolant pump/thermostat	205
2.2	Removing and installing electric coolant pump	206
2.3	Thermostat opening values	208
2.4	Removing and installing coolant pump	208
2.5	Removing and installing coolant temperature sender G62	210
2.6	Removing and installing map-controlled engine cooling system thermostat F265	211
3	Coolant pipes	213
3.1	Exploded view - coolant pipes	213
3.2	Removing and installing coolant pipes (front)	214
3.3	Removing and installing coolant pipes (top front)	214
3.4	Removing and installing coolant pipes (front centre)	216
4	Radiator/radiator fans	218
4.1	Exploded view - radiator/radiator fans	218
4.2	Exploded view - radiator cowl and radiator fan	220
4.3	Removing and installing radiator	220
4.4	Removing and installing radiator fans	226
4.5	Removing and installing auxiliary radiator	227
24	Mixture preparation - injection	229
1	Injection system	229
1.1	Overview of fitting locations - injection system	229
1.2	Checking fuel system for leaks	235
1.3	Reducing pressure in high-pressure section of injection system	235
2	Vacuum system	237
2.1	Exploded view - vacuum system	237
2.2	Checking vacuum system	237



3	Injectors	239
3.1	Removing and installing injectors	239
3.2	Cleaning injectors	243
4	Air cleaner	245
4.1	Exploded view - air cleaner housing	245
4.2	Removing and installing air cleaner housing	246
4.3	Removing and installing air filter element	248
5	Intake manifold	249
5.1	Exploded view - intake manifold (top section)	249
5.2	Exploded view - intake manifold (bottom section) with fuel rail	251
5.3	Removing and installing intake manifold (top section)	253
5.4	Removing and installing intake manifold (bottom section) with fuel rail	255
5.5	Removing and installing throttle valve module J338 / J544	259
6	Senders and sensors	260
6.1	Removing and installing fuel pressure sender G247 / G624	260
6.2	Checking fuel pressure and residual pressure (up to high-pressure pump)	260
7	Engine control unit	266
7.1	Removing and installing engine control unit J623	266
7.2	Wiring and component check with isolator boxes VAS 6606	269
8	High-pressure pump	271
8.1	Exploded view - high-pressure pump	271
8.2	Removing and installing high-pressure pump	272
8.3	Removing and installing high-pressure pipe	275
9	Lambda probe	278
9.1	Exploded view - Lambda probe	278
9.2	Removing and installing Lambda probe	278
26	- Exhaust system	281
1	Exhaust pipes/silencers	281
1.1	Exploded view - silencers	281
1.2	Separating exhaust pipes/silencers	283
1.3	Removing and installing front silencers	284
1.4	Stress-free alignment of exhaust system	286
1.5	Aligning tailpipes	287
1.6	Checking exhaust system for leaks	287
1.7	Checking function of exhaust flap	288
2	Exhaust manifold	289
2.1	Exploded view - exhaust manifold	289
2.2	Removing and installing exhaust manifold	290
3	Secondary air system	294
3.1	Exploded view - secondary air system	294
3.2	Removing and installing secondary air pump V101 / V189	296
3.3	Removing and installing combination valve	297
3.4	Checking combination valve for correct operation and leaks	298
3.5	Removing and installing senders for secondary air pressure G609 / G610	300
28	- Ignition system	301
1	Ignition system	301
1.1	Exploded view - ignition system	301
1.2	Test data - spark plugs	302
1.3	Removing and installing ignition coils	302
1.4	Removing and installing knock sensor	304
1.5	Removing and installing Hall senders	305
1.6	Removing and installing engine speed sender G28	306