



Contents

00 - Technical data	1
1 Technical data	1
1.1 Engine number	1
1.2 Engine data	1
2 Safety information	3
2.1 Safety regulations for working on fuel supply	3
2.2 Safety measures when working on vehicles with a start/stop system	3
2.3 Safety precautions when using testers and measuring instruments during a road test	4
2.4 Safety precautions when working on the cooling system	4
2.5 Safety precautions when working on the SCR system	4
2.6 Safety precautions when working on exhaust system	5
10 - Removing and installing engine	7
1 Removing and installing engine	7
1.1 Removing and installing engine cover	7
1.2 Removing engine	7
1.3 Separating engine from gearbox	14
1.4 Separating engine from dual clutch gearbox	16
1.5 Securing engine to assembly stand	18
1.6 Installing engine	20
1.7 Assembly mountings	22
1.8 Adjusting assembly mountings	23
13 - Crankshaft group	27
1 Dismantling and assembling engine	27
1.1 Poly V-belt drive with tensioning element and air conditioner compressor	27
1.2 Poly V-belt drive with tensioning roller and air conditioner compressor	30
1.3 Poly V-belt drive without air conditioning compressor	34
1.4 Removing and installing bracket for ancillaries	35
1.5 Assembly overview - toothed belt drive	36
1.6 Removing and installing engine bracket	38
1.7 Assembly overview - crankcase	42
2 Removing and installing sealing flange and flywheel	44
2.1 Assembly overview - Sealing flange, belt pulley end	44
2.2 Renewing crankshaft oil seal - pulley end	45
2.3 Removing and installing sealing flange - pulley end	47
2.4 Assembly overview - Dual-mass flywheel and sealing flange	49
2.5 Removing and installing dual-mass flywheel	51
2.6 Renewing crankshaft sealing flange - flywheel end	52
2.7 Removing and installing engine speed sender G28	59
3 Pistons and conrods	61
3.1 Assembly overview - pistons and conrods	61
3.2 Piston and cylinder dimensions	64
3.3 Separating new conrods	64
3.4 Bearing shells - installation position	65
3.5 Piston and cylinder dimensions	65
3.6 Checking piston projection at TDC	65
3.7 Measuring radial clearance of conrods	67
4 Crankshaft	69
4.1 Assembly overview - crankshaft	69
4.2 Crankshaft dimensions	69
4.3 Renewing needle bearing in crankshaft	70



15 - Cylinder head, valve gear	72
1 Cylinder head	72
1.1 Assembly overview - cylinder head cover	72
1.2 Removing and installing cylinder head cover	74
1.3 Removing, installing and tensioning toothed belt	77
1.4 Assembly overview - cylinder head	84
1.5 Removing and installing cylinder head	86
1.6 Removing and installing vacuum pump	95
1.7 Compression test	96
2 Valve gear	98
2.1 Assembly overview - valve gear	98
2.2 Removing and installing camshafts	101
2.3 Measuring axial clearance of camshaft	108
2.4 Measuring radial clearance of camshafts	109
2.5 Removing and installing camshaft oil seal	109
2.6 Checking hydraulic compensation elements	112
2.7 Renewing valve stem seals with cylinder head installed	112
2.8 Renewing valve stem seals with cylinder head removed	116
2.9 Valves	119
17 - Lubrication	121
1 Engine oil:	121
1.1 Oil capacities	121
1.2 Checking engine oil level	121
2 Parts of lubrication system	122
2.1 Assembly overview - oil pump, sump, balance shaft module	122
2.2 Removing and installing oil level and oil temperature sender G266	126
2.3 Removing and installing oil sump	126
2.4 Removing and installing oil pump	130
2.5 Removing balancer shaft module	131
2.6 Installing a new balancer shaft module	133
2.7 Installing a previously used balancer shaft module again	135
3 Oil filter bracket and engine oil cooler	137
3.1 Assembly overview - oil filter bracket and engine oil cooler	137
3.2 Removing and installing oil filter bracket with engine oil cooler	138
3.3 Removing and installing oil pressure switch F1	141
3.4 Checking oil pressure switch F1	142
3.5 Checking oil pressure	143
19 - Cooling	145
1 Parts of cooling system	145
1.1 Assembly overview - parts of cooling system, body side	145
1.2 Assembly overview - parts of cooling system, engine side	147
1.3 Assembly overview - coolant pump and thermostat	148
1.4 Coolant hose connection diagram	149
2 Repairing cooling system	150
2.1 Removing and installing cowling together with radiator fan V7 and radiator fan on right of radiator V35	150
2.2 Removing and installing radiator	151
2.3 Removing and installing coolant pump	152
2.4 Removing and installing 4/2-way valve with thermostat	154
2.5 Draining and adding coolant	159
2.6 Coolant pipes, coolant temperature sender	163
2.7 Checking cooling system for leaks	174



20 - Fuel supply system	178
1 Safety regulations for working on fuel supply	178
2 Rules for cleanliness	179
3 Repair instructions if tank has been filled with incorrect fuel	180
3.1 Step 1 (Engine was started with incorrect fuel)	180
3.2 Step 2 (Engine was not started with incorrect fuel)	181
3.3 Step 3 (There are filings in fuel delivery unit and fuel tank)	182
3.4 Step 4 (There are no filings in fuel delivery unit and fuel tank)	182
3.5 Step 5 (There are filings in high-pressure pump)	183
3.6 Step 6 (There are no filings in high-pressure pump)	183
4 Parts of fuel supply system	184
4.1 Assembly overview - fuel tank	184
4.2 Assembly overview - fuel delivery unit, fuel gauge sender and suction jet pump	185
4.3 Removing and installing fuel delivery unit	186
4.4 Removing and installing fuel gauge sender G	188
4.5 Emptying fuel tank	189
4.6 Removing and installing fuel tank	192
5 Repairing fuel supply	194
5.1 Assembly overview - fuel filter	194
5.2 Removing and installing fuel filter	195
5.3 Checking fuel system pressurisation pump G6	196
5.4 Assembly overview - accelerator mechanism	200
5.5 Removing and installing accelerator pedal module	201
21 - Turbocharging/supercharging	204
1 Exhaust turbocharger	204
1.1 Safety precautions	204
1.2 Rules for cleanliness	204
1.3 Assembly overview - turbocharger	205
1.4 Removing and installing turbocharger	207
1.5 Replacing vacuum unit with position sender for charge pressure positioner G581	211
2 Charge air system	217
2.1 Installing hose connections with plug-in connectors	217
2.2 Installing hose connections with corrugated pipe connection	218
2.3 Assembly overview - parts of charge air cooling	218
2.4 Removing and installing charge air cooler	219
2.5 Checking charge air system for leaks	220
2.6 Vacuum hose connection diagram	224
2.7 Checking vacuum system	224
23 - Mixture preparation - injection	228
1 Diesel direct injection system	228
1.1 Safety precautions	228
1.2 Rules for cleanliness	228
1.3 System layout	229
2 High-pressure pump	231
2.1 Assembly overview - high-pressure pump	231
2.2 Removing and installing high-pressure pump	232
2.3 Filling/bleeding fuel system	235
2.4 Checking for leaks in the fuel system	236
3 Injectors	237
3.1 Assembly overview - injectors	237
3.2 Carrying out adaptation for injector delivery calibration	240
3.3 Checking for injectors sticking open	241



3.4	Removing and installing injectors	242
3.5	Installing high-pressure lines	246
3.6	Checking fuel pressure regulating valve N276	247
3.7	Removing and installing fuel pressure regulating valve N276	249
3.8	Removing and installing fuel pressure sender G247	250
3.9	Removing and installing fuel rail	252
4	Intake manifold	256
4.1	Assembly overview - intake manifold with attachments	256
4.2	Removing and installing throttle valve module J338	257
4.3	Removing and installing intake manifold	258
5	Air filter	262
5.1	Assembly overview - air filter	262
5.2	Removing and installing air filter housing	263
5.3	Removing and installing air mass meter G70	265
6	Lambda probe and pressure differential sender	266
6.1	Removing and installing Lambda probe G39 with Lambda probe heater Z19	266
6.2	Removing and installing pressure differential sender G505	267
7	Engine (motor) control unit	269
7.1	Removing and installing engine (motor) control unit J623	269
7.2	Removing and installing anti-theft engine control unit J623	270
26	- Exhaust system	272
1	Front exhaust pipe with particulate filter	272
1.1	Assembly overview - front exhaust pipe with particulate filter	272
1.2	Removing and installing particulate filter	274
2	Silencer	282
2.1	Assembly overview - silencers	282
2.2	Aligning exhaust system free of stress	283
2.3	Installation position and specified torque of clamp	283
3	Exhaust gas temperature regulation	285
3.1	Assembly overview - exhaust gas temperature regulation	285
3.2	Removing and installing exhaust gas temperature sender 1 G235	286
3.3	Removing and installing exhaust gas temperature sender 3 G495	287
3.4	Removing and installing exhaust gas temperature sender 4 G648	289
4	SCR system (selective catalytic reduction)	290
4.1	Assembly overview - reduction catalytic converter	290
4.2	Assembly overview - tank for reducing agent	292
4.3	Removing and installing heater element (heater cup)	293
4.4	Removing and installing injector for reduction agent N474	297
4.5	Draining reducing agent tank	298
4.6	Removing and installing reducing agent tank	300
5	Exhaust gas recirculation system	304
5.1	Assembly overview - exhaust gas recirculation	304
5.2	Checking changeover for exhaust gas recirculation cooler	305
5.3	Removing and installing exhaust gas recirculation cooler	305
5.4	Checking exhaust gas recirculation cooler for leaks	308
5.5	Cleaning exhaust gas recirculation system	312
28	- Glow plug system	318
1	Checking glow plug system	318
1.1	Removing and installing glow plugs	318
1.2	Removing and installing automatic glow period control unit J179	320