Contents

00 - Technical data 1

1 Safety information 1
1.1 Safety precautions when working on air conditioning systems 1
1.2 Safety precautions when working on high-voltage system 2
1.3 Safety precautions when working in the vicinity of high-voltage components 2
1.4 Safety precautions when tow-starting or towing 3

2 Repair instructions 4
2.1 Rules for cleanliness when working on high-voltage system 4

3 General information on air conditioning 5
3.1 Other reference material 5
3.2 Basics of air conditioning technology 5
3.3 Vapour pressure table for refrigerant R134a 7
3.4 Refrigerant R134a 8
3.5 Properties of refrigerant R134a 9
3.6 Refrigerant oil 11
3.7 Comfort 12
3.8 How air conditioning works 13
3.9 General work safety 13
3.10 Safety measures when working on vehicles with air conditioning and when working with refrigerant R134a 16
3.11 Basics for working on refrigerant circuit 17

4 General information on refrigerant circuit 20
4.1 Components of refrigerant circuit 20
4.2 Design of refrigerant circuit 31
4.3 Evacuation and charging valves for quick-release couplings of air conditioner service station on refrigerant circuit 32
4.4 Switches and senders in refrigerant circuit and related connections 34
4.5 Electrical components not installed in refrigerant circuit 39
4.6 Pressures and temperatures in refrigerant circuit 42
4.7 Refrigerant circuit with expansion valve 42
4.8 Refrigerant circuit with restrictor and reservoir 44
4.9 Test and measurement work that can be performed using a pressure gauge 46
4.10 Air conditioner service and recycling equipment 47
4.11 Notes to repairs on refrigerant circuit 48

5 Laws and regulations 49
5.1 Laws and regulations 49
5.2 Recycling and refuse law 54
5.3 Converting R12 refrigerant circuits to R134a refrigerant circuits and repairing them (retrofitting) 55
5.4 Maintaining records on refrigerant 55

6 Refrigerant circuit 56
6.1 Important repair notes on air conditioning 56
6.2 Converting refrigerant circuits from R12 refrigerant to R134a 56

7 Working with the air conditioner service station 57
7.1 Important instructions for working with the air conditioner service station 57
7.2 Connecting a air conditioner service station for measuring and testing 58
7.3 Drain the refrigerant circuit using the air conditioner service station. 59
7.4 Evacuating refrigerant circuit using air conditioner service station 59
7.5 Filling refrigerant circuit with air conditioner service station. 61
7.6 Bringing air conditioning system into service after charging 62
7.7 Charging the container in the air conditioning service station with refrigerant 62
7.8 Emptying air conditioner service station 63

8 Detecting leaks in refrigerant circuit 64
8.1 Leak detection in refrigerant circuit using compressed air or nitrogen 65
8.2 Searching for leaks in refrigerant circuits using leak detector V.A.G 1796 66
8.3 Detecting leaks in refrigerant circuit using leak detecting system VAS 6196 or leak detecting system VAS 6201 or a later model 67
9 Clearing refrigerant circuit of contaminants 75
9.1 Vehicles with high-voltage system (hybrid vehicles) 75
9.2 Blowing through refrigerant circuit with compressed air and nitrogen 76
9.3 Flushing refrigerant circuit with refrigerant R134a 78
10 Clearing refrigerant circuit of contaminants, commercial vehicles 110
10.1 Vehicles with high-voltage system 110
10.2 Flushing refrigerant circuit with refrigerant R134a 111
10.3 Adapters for setting up flushing circuits 111
10.4 Procedure for setting up and flushing refrigerant circuit, Amarok 2010 ► 115
10.5 Procedure for setting up and flushing refrigerant circuit, Caddy 2004 ► 121
10.6 Procedure for setting up and flushing refrigerant circuit, Crafter ►2017 128
10.7 Procedure for setting up and flushing refrigerant circuit, Crafter 2017 ► or MAN TGE ►, Crafter Grand California ► 145
10.8 Procedure for setting up and flushing refrigerant circuit, Transporter 2016 ►, Transporter 2020 ► 162
11 Complaints 178
11.1 Possible complaints about refrigerant circuit 178
11.2 Odours from heater and air conditioning unit 179
12 Connecting the air conditioning service station 182
12.1 For vehicles that have connections on both low-pressure and high-pressure sides of refrigerant circuit 182
13 Checking pressures on vehicles 183
13.1 Checking pressures in the refrigerant circuit (using a air conditioning service station) 183
13.2 Checking systems with a restrictor and collector (with internally regulated air conditioner compressor) 187
13.3 Checking systems with an expansion valve and reservoir (with internally regulated air conditioner compressor) 191
13.4 Checking systems with an expansion valve and reservoir (without regulated air conditioner compressor) 196
13.5 Checking systems with a restrictor and reservoir and air conditioner compressor regulating valve N280 (with externally regulated air conditioner compressor) 197
13.6 Checking systems with an expansion valve, receiver and air conditioner compressor regulating valve N280 (with externally regulated air conditioner compressor) 202
13.7 With expansion valve, receiver and electrical air conditioner compressor 213
14 Renewing components 214
14.1 In the event of leaking or damaged components (apart from the air conditioner compressor, receiver or reservoir) 215
14.2 Renew the air conditioner compressor 217
14.3 Replace receiver or reservoir and restrictor 219
15 Testing equipment and tools 222
15.1 List of test equipment, tools and materials 222