Contents

00 - Technical data 1
1 Gearbox identification 1
1.1 Location on gearbox 1
1.2 Code letters and date of manufacture of gearbox arrow 1 1
2 Notes on automatic gearbox 099 2
2.1 Notes on automatic gearbox 099 2
3 Code letters, engine allocation, ratios, equipment 3
4 Capacities 8
4.1 Planetary gear 8
4.2 Final drive 8
5 Repair instructions 9
5.1 Repair instructions 9

32 - Torque converter 12
1 Torque converter 12
1.1 Identification of torque converter 12
1.2 Allocation of torque converter 12
1.3 Removing and installing torque converter oil seal 15
1.4 Draining torque converter 15

37 - Controls, housing 17
1 Electrical and electronic components and their locations 17
2 Repairing selector mechanism for vehicles before 05.00 23
2.1 Checking selector mechanism 23
2.2 Checking and adjusting selector lever cable 24
2.3 Dismantling and assembling selector mechanism 24
2.4 Removing and installing selector lever cable 25
2.5 Dismantling and assembling selector lever 29
2.6 Adjusting starter inhibitor switch in right-hand drive vehicles 31
3 Repairing selector mechanism for vehicles after 06.00 32
3.1 Checking selector mechanism 32
3.2 Checking and adjusting selector lever cable 33
3.3 Checking operation of the ignition key withdrawal lock 35
3.4 Removing and installing selector lever handle 36
3.5 Removing and installing selector mechanism 38
3.6 Dismantling and assembling selector mechanism on vehicles before 06.01 40
3.7 Dismantling and assembling selector mechanism on vehicles after 07.01 42
3.8 Removing and installing selector lever lock solenoid N110 in vehicles before 06.01 44
3.9 Removing and installing selector lever lock solenoid N110 in vehicles after 07.01 44
3.10 Removing and installing pull rod top part 48
3.11 Removing and installing selector lever cable 49
3.12 Removing and installing locking cable 53
3.13 Adjusting locking cable in vehicles before 06.01 58
3.14 Adjusting locking cable in vehicles after 07.01 59
4 Checking gearbox 60
4.1 Connecting vehicle diagnosis, testing and information system VAS 5051 60
4.2 Checking shift points 60
4.3 Checking stall speed 60
4.4 Fault finding table for “4-speed automatic gearbox” 61
4.5 Repair of “4-speed automatic gearbox” with an exchange component 61
4.6 Measuring main pressure 61
5 Removing and installing gearbox 65

5.1 Removing and installing gearbox for vehicles before 05.00 65
5.2 Removing and installing gearbox for vehicles after 06.00 73
6 Checking ATF level and topping up 82
6.1 Checking ATF level 83
6.2 Topping up ATF 85
6.3 Renewing ATF 86
7 Gearbox with selector elements 87
8 Dismantling and assembling gearbox 90
8.1 Removing and installing ATF cooler and ATF filler pipe 90
8.2 Dismantling and assembling planetary gearbox -Overview- 90
8.3 I - Removing and installing ATF pump to supporting tube 91
8.4 II - Removing and installing reverse clutch -K2- to large sun gear 93
8.5 III - Removing and installing freewheel and reverse gear brake -B1- 94
8.6 IV - Planet carrier and gearbox housing with input gear and cover 95
8.7 Dismantling and assembling planetary gearbox 97
8.8 Overview of all planetary gearbox adjustments 110
8.9 Adjusting planet carrier 112
8.10 Adjusting reverse gear brake -B1- 116
8.11 Adjusting clutch play between -K1- and -K2- 119
8.12 Adjusting 2nd and 4th gear brake -B2- 122

38 - Gears, control 131
1 Dismantling and assembling ATF pump 131
2 Dismantling and assembling freewheel with -B1- piston 133
3 Dismantling and assembling 1st to 3rd gear clutch -K1- 135
4 Dismantling and assembling reverse gear clutch -K2- 138
5 Dismantling and assembling 3rd and 4th gear clutch -K3- with turbine shaft 141
6 Removing and installing valve body 144
7 Dismantling and assembling parking lock 149

39 - Final drive - differential 154
1 Checking oil in final drive 154
2 Removing and installing oil seal for stub shaft or flange shaft 155
2.1 When renewing oil seal on left 155
2.2 When renewing oil seal on right 157
3 Dismantling and assembling final drive 160
3.1 Repair overview of final drive 160
3.2 Removing and installing bearing housing 161
3.3 Removing and installing input gear 166
3.4 Removing and installing drive shaft 169
3.5 Removing and installing differential 179
3.6 Dismantling and assembling differential 184
4 Adjusting final drive 193
4.1 Overview of adjustments 193
4.2 Adjustments to be completed after replacing individual components 193
4.3 Adjusting drive shaft 194
4.4 Adjusting input gear 197
4.5 Adjusting differential 198
5 Definitions 205