



Contents

50 - Body - front	1
1 Body - front section	1
1.1 Front end with complementary parts - assembly overview	1
1.2 Front end with complementary parts - remove and install	1
1.3 Front end - service position	2
1.4 Front wing - assembly overview	4
1.5 Engine compartment upper partition panel - replacing	5
55 - Bonnet, rear lid	7
1 Bonnet	7
1.1 Assembly overview	7
1.2 Bonnet - remove and install	8
1.3 Bonnet - adjust	8
1.4 Bonnet hinge - remove and install	10
1.5 Bonnet latch operation cable - assembly overview	10
1.6 Bonnet latch Bowden cable - remove and install	11
1.7 Bonnet upper latch - remove and install	13
1.8 Bonnet lower latch - remove and install	14
2 Rear lid (Gol)	16
2.1 Assembly overview	16
2.2 Rear door shock absorber - remove and install	17
2.3 Rear lid shock absorber - remove the gas	17
2.4 Rear lid trim - remove and install	18
2.5 Rear lid - remove and install	18
2.6 Rear lid hinge - remove and install	19
2.7 Rear lid - adjust	20
2.8 Housing with latch cylinder - assembly overview	21
2.9 Housing with Latch cylinder - remove and install	22
2.10 Latch cylinder - remove and install	23
2.11 Door latch - remove and install	23
2.12 Rear lid unlocking motor V139 - remove and install	24
3 Rear lid (Voyage)	26
3.1 Assembly overview	26
3.2 Rear lid trim - remove and install	27
3.3 Rear lid - remove and install	27
3.4 Rear lid hinge - assembly overview	28
3.5 Rear lid hinge - remove and install	29
3.6 Rear lid - adjust	29
3.7 Housing with latch cylinder - assembly overview	33
3.8 Housing with Latch cylinder - remove and install	34
3.9 Latch cylinder - remove and install	34
3.10 Door latch - remove and install	35
3.11 Rear lid unlocking motor V139 - remove and install	35
4 Tailgate (Saveiro)	37
4.1 Tailgate buffer - adjust	37
4.2 Tailgate buffer - lubricate	38
4.3 Tailgate lock - remove and install	38
4.4 Rod drive - assembly overview	39
4.5 Rod driver - remove and install	40
4.6 Tailgate handle with cylinder - assembly overview	41
4.7 Tailgate handle with cylinder - remove and install	42
4.8 Tailgate sustaining cable - remove and install	42
4.9 Latch cylinder - remove and install	43



4.10	Tailgate damper - remove and install	43
4.11	Dropside shock absorber - remove the gas	44
4.12	Tailgate - remove and install	44
4.13	Tailgate - adjust	45
5	Fuel reservoir nozzle compartment and lid set	47
5.1	Fuel reservoir nozzle compartment lid (Gol and Voyage) - remove and install	47
5.2	Fuel reservoir nozzle compartment lid (Saveiro) - remove and install	48
57	Front doors, door components, central locking	49
1	Front door	49
1.1	Tools	49
1.2	Front door - assembly overview	50
1.3	Door - remove and install	51
1.4	Door - adjust	52
1.5	Door - disassemble and assemble	54
1.6	Door - replace	54
1.7	Front door arrester - adjust	55
1.8	Door limiter - remove and install	55
1.9	Internal handle - replace	56
1.10	Front door external handle and lock - assembly overview	56
1.11	Lock cylinder housing - remove and install	58
1.12	Latch cylinder - remove and install	59
1.13	Door handle - remove and install	59
1.14	External door handle - replace	61
1.15	Door lock - remove and install	61
1.16	Lock button (locking rod) - remove and install	62
1.17	Door lock - replace	63
1.18	Lock Bowden cable - replace	63
1.19	Door sealing membrane - remove and install	64
1.20	Internal door trim - remove and install	66
2	Central locking	68
2.1	Central locking installation locations overview	68
2.2	Battery of key with radio remote command (articulated) - assembly overview	74
2.3	Battery of key with radio remote command (articulated) - remove and install	74
2.4	Key - synchronize	75
58	Rear doors, door components	77
1	Rear passenger doors	77
1.1	Rear passenger doors - assembly overview	77
1.2	Door - remove and install	78
1.3	Door - adjust	79
1.4	Rear passenger door - disassemble and assemble	81
1.5	Door - replace	81
1.6	Rear door arrester - adjust	82
1.7	Door limiter - remove and install	82
1.8	Internal handle - replace	83
1.9	Rear door external handle and lock - assembly overview	83
1.10	External handle housing - remove and install	85
1.11	External door handle - remove and install	86
1.12	External door handle - replace	88
1.13	Door lock - remove and install	88
1.14	Door lock - replace	92
1.15	Lock button (locking rod) - remove and install	92
1.16	Lock Bowden cable - replace	93
1.17	Door sealing membrane - remove and install	93
1.18	Internal door trim - remove and install	95



61 - Convertible roof, hardtop, canopy	97
1 Tonneau cover (Saveiro)	97
1.1 Assembly overview	97
1.2 Tonneau cover - remove and install	98
1.3 Tonneau cover longitudinal member - assembly overview	101
1.4 Tonneau cover longitudinal member - remove and install	101
1.5 Tonneau cover longitudinal member (Saveiro Cross ◀10/06/2014) - replace	102
63 - Bumpers	104
1 Front bumper	104
1.1 Front protector - assembly overview	104
1.2 Front protector - remove and install	104
1.3 Front license plate fastening - install	107
1.4 Front license plate fastening (Gol Rallye / Saveiro Cross)- install	107
1.5 Front protector support - assembly overview	107
2 Rear bumper (Gol)	109
2.1 Rear protector - assembly overview	109
2.2 Rear protector - remove and install	110
2.3 Rear license plate fastening - install	113
2.4 Foamed rear protector support - assembly overview	113
3 Rear bumper (Voyage)	115
3.1 Rear protector - assembly overview	115
3.2 Rear protector - remove and install	116
3.3 Rear license plate fastening - install	119
3.4 Foamed rear protector support - assembly overview	120
4 Rear bumper (Saveiro)	121
4.1 Support and side protector - assembly overview	121
4.2 Side protector - remove and install	121
4.3 Support and central protector - assembly overview	122
4.4 Central protector - remove and install	123
4.5 Rear license plate fastening - install	124
64 - Glazing	126
1 Repair instructions	126
1.1 Tools	126
1.2 Auxiliary materials - Brazilian market	128
1.3 Auxiliary materials for the export market	128
1.4 Matching table	129
1.5 Stickers for engraving the VIS number on the windows (only for Brazil) - supply	129
1.6 Undamaged glass - prepare for install	129
1.7 New glass - prepare for install	129
1.8 Body flange - prepare to install the window	130
1.9 Assembly instructions	131
1.10 Minimum adhesive drying time	132
1.11 Paint damage - repair	133
1.12 Cleaning in case of resulting adhesive residues	133
1.13 Data stickers	133
2 Windscreen	136
2.1 Windscreen - assembly overview	136
2.2 Windscreen - remove	137
2.3 Windscreen - install	137
3 Side window	138
3.1 Rear side glass (2-door Gol) - assembly overview	138
3.2 Undamaged rear side glass (2-door Gol) - remove	138



3.3	Damaged rear side glass (2-door Gol) - remove	139
3.4	Rear side glass (2-door Gol) - install	140
3.5	Fixed rear side window (Saveiro "extended cab") - assembly overview	140
3.6	Undamaged fixed rear side window (Saveiro "extended cab") - remove	141
3.7	Damaged fixed rear side window (Saveiro "extended cab") - remove	142
3.8	Fixed rear side window (Saveiro "extended cab") - install	142
3.9	Rear side window (Saveiro "double cab") - assembly overview	142
3.10	Rear side window (Saveiro "extended cab") - remove and install	144
4	Rear window	146
4.1	Rear window (Gol) - assembly overview	146
4.2	Undamaged rear window (Gol) - remove	146
4.3	Damaged rear window (Gol) - remove	147
4.4	Rear window (Gol) - install	148
4.5	Rear window (Voyage) - assembly overview	148
4.6	Undamaged rear window (Voyage) - remove	148
4.7	Damaged rear window (Voyage) - remove	149
4.8	Rear window (Voyage) - install	150
4.9	Fixed rear window (Saveiro "single cab") - assembly overview	150
4.10	Fixed rear window (Saveiro "extended cab") - assembly overview	151
4.11	Fixed rear window (Saveiro "double cab") - assembly overview	152
4.12	Sliding rear window (Saveiro "single cab") - assembly overview	153
4.13	Sliding rear window (Saveiro "extended cab") - assembly overview	154
4.14	Undamaged fixed or sliding rear window (Saveiro) - remove	154
4.15	Rear fixed or sliding window (Saveiro) - install	156
5	Door window glass	157
5.1	Front door window glass - assembly overview	157
5.2	Front door window glass - remove and install	157
5.3	Rear door window glass - assembly overview	158
5.4	Rear door window glass - remove and install	159
5.5	Rear door fixed window - assembly overview	160
5.6	Undamaged fixed rear door window - remove	161
5.7	Damaged fixed rear door window - remove	162
5.8	Fixed rear door window - install	162
6	Window drive mechanism	163
6.1	Convenience system window drive mechanism (automatic window closing and opening mechanism) with force limiter (anti-crushing function)	163
6.2	Central control unit for glass command J1015 - remove and install	165
6.3	Window drive mechanism - remove and install	166
6.4	Window drive motor V147/ V148 - remove and install	167
6.5	Front door window crank - remove and install	168
6.6	Rear door window drive mechanism - remove and install	168
6.7	Rear window control motor V26 / V27 - remove and install	169
6.8	Rear door window drive crank - remove and install	170
7	Window channels and trim strips	171
7.1	Front door window channel - remove and install	171
7.2	Front door window internal trim - remove and install	171
7.3	Front door window external trim - replace	171
7.4	Rear door window channel - remove and install	172
7.5	Rear door window internal trim - remove and install	172
7.6	Rear door window external trim - replace	172
66	Exterior equipment	174
1	Materials used and operational care required	174
1.1	Auxiliary materials for Brazilian market	174
1.2	Auxiliary materials for export market	174



1.3	Matching table	175
1.4	Paint damage - repair	175
1.5	Cleaning in case of dirt residues resulting from handling of polyurethane adhesive (PU)	175
1.6	Minimum adhesive drying time	175
2	Wheel arch protector	176
2.1	Front wheel arch protector - remove and install	176
2.2	Rear wheel arch protector - remove and install	177
3	External rear-view mirror	178
3.1	External rear-view mirror - assembly overview	178
3.2	External rearview mirror - assembly overview - continued	179
3.3	Exterior rear-view mirror - remove and install	179
3.4	Mirror glass - remove and install	180
3.5	Mirror glass - remove and install	181
3.6	Turn signal (Blinker) - remove and install	182
4	External linings	183
4.1	Windscreen lower trim - assembly overview	183
4.2	Windscreen lower trim - remove and install	183
4.3	External linings on pillars and doors - replace	184
4.4	External B-pillar coverings (Saveiro - single cab) - replace	185
4.5	Footwell cover (Saveiro) - replace	187
4.6	Lower longitudinal member external lining - replace	189
5	Side trims, roof	191
5.1	Front door trims - replace	191
5.2	Rear door trims - replace	192
5.3	Side trims (Gol - 2-door) - replace	194
5.4	Side trims (Saveiro Cross) - assembly overview	196
5.5	Front door trim (Saveiro Cross) - replace	197
5.6	Rear side panel trim (Saveiro Cross) - replace	199
5.7	Door trims (Voyage Evidence) - replace	201
5.8	Decorative side strip (Gol Rallye / Track / Seleção / Cup and Voyage Seleção) - replace	204
5.9	Rear protector decorative strip (Gol Rallye and Gol Track) - replace	206
5.10	Decorative side stripe (Saveiro Trooper) - replace	207
5.11	Decorative side stripe (Saveiro SURF) - replace	209
5.12	Rear cover trim (Voyage) - replace	210
5.13	Roof trim - assembly overview	212
5.14	Roof lining (Saveiro) - remove and install	213
6	Front grille, front protector grids, rear protector frames	215
6.1	Radiator grille - assembly overview	215
6.2	Radiator grille strips - assembly overview	216
6.3	Front protector grilles - assembly overview	216
6.4	Front protector central and lateral grid strips - assembly overview	218
6.5	Front protector central and lateral grid strips - remove and install	218
7	Side member trim	220
7.1	Longitudinal lower trim (Gol Rallye and Gol Track) - general assembly overview	221
7.2	Longitudinal lower trim (Gol Rallye and Gol Track) - replace	221
7.3	Longitudinal member lower trim (Saveiro Cross) - assembly overview	226
7.4	Longitudinal member lower trim (Saveiro Cross) - replace	226
8	Rear wing and side panel trim	229
8.1	Front protector trim (Saveiro and Gol Track) - assembly overview	230
8.2	Front protector trim (Saveiro and Gol Track) - replace	230
8.3	Front protector trim (Saveiro Cross and Gol Rallye) - assembly overview	231
8.4	Front protector trim (Saveiro Cross and Gol Rallye) - replace	232
8.5	Front wing trim (Saveiro) - assembly overview	233



8.6	Front wing trim (Saveiro) - replace	234
8.7	Front wing trim (Saveiro Cross) - assembly overview	236
8.8	Front wing trim (Saveiro Cross) - replace	237
8.9	Front wing trim (Gol Rallye) - assembly overview	238
8.10	Front wing trim (Gol Rallye) - replace	239
8.11	Rear side panel trim (Saveiro) - assembly overview	241
8.12	Rear side panel trim (Saveiro) - replace	242
8.13	Rear side panel trim (Saveiro Cross) - assembly overview	244
8.14	Rear side panel trim (Saveiro Cross) - replace	245
8.15	Rear side panel trim (Gol Rallye and Gol Track) - general assembly overview	246
8.16	Rear side panel trim (Gol Rallye and Gol Track) - replace	247
8.17	Rear side protector trim (Saveiro) - replace	250
8.18	Front protective trim (Gol Rallye) - remove and install	251
9	Cargo compartment and frames protector (Saveiro)	254
9.1	Upper tailgate frame - replace	254
9.2	Cargo compartment upper frame - replace	255
9.3	Bedliner grid - assembly overview	258
9.4	Cargo compartment protection grid - remove and install	259
9.5	External B-pillar frame - replace	259
9.6	Rear window glass upper and lower frame - remove and install	262
9.7	Bedliner - assembly overview	264
9.8	Bedliner - remove and install	264
9.9	Cargo tying adjustable hooks track (vehicle without tonneau cover) - remove and install	265
9.10	Cargo tying adjustable hooks track (vehicle with tonneau cover) - remove and install	266
9.11	Cargo compartment adjustable hooks - remove and install	268
10	Front grid, front protector grids, rear protector frames	269
10.1	Front spoiler (Saveiro Cross and Gol Rallye) - assembly overview	269
10.2	Front spoiler (Saveiro Cross and Gol Rallye) - remove and install	269
10.3	Front protector central grille (Saveiro Cross and Gol Rallye) - assembly overview	270
10.4	Front protector central grid (Saveiro Cross and Gol Rallye) - remove and install	271
10.5	Front protector side grille (Saveiro Cross and Gol Rallye) - assembly overview	272
10.6	Front protector side grid (Saveiro Cross and Gol Rallye) - remove and install	273
10.7	Lower rear protector frame (Saveiro Cross) - replace	274
10.8	Lower rear side protector frame (Saveiro Cross) - replace	276
10.9	Rear lower spoiler (Gol Rallye) - replace	278
11	Roof rack (Saveiro)	282
11.1	Roof rack (single cab) - assembly overview	282
11.2	Roof rack (single cab) - remove and install	282
11.3	Roof rack (extended and double cab) - assembly overview	285
11.4	Roof rack (extended and double cab) - remove and install	285
11.5	Roof rack (Saveiro Cross) - assembly overview	287
11.6	Roof rack (Saveiro Cross) - remove and install	287
11.7	Roof rack extension (Saveiro Cross) - assembly overview	289
11.8	Roof rack extensor (Saveiro Cross) - remove and install	289
11.9	Roof rack extensor cover (Saveiro Cross) - remove and install	291
11.10	Bed rack (Saveiro Cross "extended cab") - assembly overview	292
11.11	Cargo compartment rack (Saveiro Cross "extended cab") - remove and install	292
12	Badges	295
12.1	Volkswagen Badge - replace	295
12.2	Model badge - replace	297
12.3	(1.6) version badge - replace	298
12.4	(MSI) version badge - replace	298
12.5	"Imotion" Badge - replace	299
12.6	"Rallye" Badge (Gol Rallye ►02.14) and "TRACK" - replace	300
12.7	"Rallye" Badge (Gol Rallye 02.14►) - replace	301



12.8	“Seleção” Badge (Gol Seleção MY 14 ►) - replace	301
12.9	“Seleção” Badge (Voyage Seleção MY 14 ►) - replace	303
12.10	“Bandeira” Badge (Gol Seleção MY 14 ►) - replace	304
12.11	“Bandeira” Badge (Voyage 1.0L Seleção MY 14 ►) - replace	305
12.12	“Bandeira” Badge (Voyage 1.6L Seleção MY 14 ►) - replace	306
12.13	Version badge (Bluemotion Technology) - replace	307
12.14	“VW Adhesive” Badge (Rear Window - Gol Seleção MY 14 ►) - replace	308
12.15	“VW Adhesive” Badge (Rear Window - Voyage Seleção MY 14 ►) - replace	309
12.16	Version badge (door) - replace	310
12.17	“SPORTLINE” Badge - replace	310
12.18	“CBF” Badge on the front bumper (Gol and Voyage Seleção MY 14 ►) - replace	311
12.19	Version badge (Seleção) on ashtray - replace	312
12.20	Version badge “SURF” on the front fender (Saveiro) - replace	312
12.21	“Saveiro Cross” and “Saveiro” badge on the tailgate - replace	313
12.22	Version badge “Fun” - replace	314
12.23	Version badge “Evidence” on the front fender (Voyage) - replace	317
12.24	Version badge (Rock in Rio) on front wing - replace	319
12.25	Side decorative strip (Gol Rock in Rio) - replace	320
12.26	Side decorative strip (Saveiro Rock in Rio) - replace	322
12.27	Decorative stripe on the rear protector (Gol Rock in Rio) - replace	324
12.28	Decorative stripe on the rear protector (Saveiro Rock in Rio) - replace	325
12.29	Version badge (Rock in Rio) on ashtray - replace	327
13	Spoiler	328
13.1	Roof spoiler (Gol) - assembly overview	328
13.2	Observations for the execution of the removal and installation of the spoiler	329
13.3	Removal	329
13.4	Installation	331
13.5	Roof spoiler (Voyage) - assembly overview	337
13.6	Observations for the execution of the removal and installation of the spoiler	338
13.7	Removal	338
13.8	Installation	340
14	Saveiro Cross components	346
14.1	Saveiro Cross components - assembly overview	346
15	Gol Rallye Components	347
15.1	Gol Rallye Components - assembly overview	347