

Contents

00 - Technical data	1
1 Qualification	1
2 Safety precautions	2
2.1 Safety precautions	2
2.2 Safety precautions when working on the high-voltage system	4
2.3 Safety precautions when working in the vicinity of high-voltage components	5
2.4 Safety precautions when working on the cooling system	5
2.5 Safety precautions when using testers and measuring instruments during a road test	6
2.6 Work that requires high-voltage system to be de-energised	6
3 Repair instructions	7
3.1 Important notes	7
3.2 General notes and quality-related information	7
3.3 Information on handling fine dust, aluminium dust and steel dust	8
3.4 Routing and attachment of pipes, hoses and wiring	9
3.5 Contact corrosion	9
3.6 Bonding surfaces for adhesive strips	10
3.7 Self-locking bolts	11
3.8 Identification plates	11
3.9 Impact wrenches	11
3.10 Dent removal	11
3.11 Matching the surface contour	12
3.12 Straightening and re-alignment of body parts	13
3.13 Procedure for accident repairs	14
4 Vehicle identification data	15
4.1 Type plate and vehicle identification number	15
4.2 Vehicle data sticker	15
5 Aluminium panels	17
5.1 Wing panel	17
6 Galvanised body panels, high-strength and extra-high-strength steel	18
7 Renewing studs	23
8 Extraction systems for steel/aluminium body repair station ("multi-material-mix" workplace)	24
9 Moulded foam inserts	26
10 Repairing thread for seat belt anchorage	28
11 Thread repair for M6 pop rivet nut	29
12 Body panel gaps/shut lines	30
13 Laser welding	34
14 Processing body structure adhesive D 180 004 M2	35
14.1 Preparing bonding surfaces	36
15 Body dimensions	49
16 Tools	59
17 Straightening jig	64
50 - Body - front	65
1 Intermediate piece - Renewal	65
1.1 Tools	65
1.2 Procedure	65
2 Upper wheel housing longitudinal member - Renewal	69
2.1 Tools	69
2.2 Procedure	69



3	Suspension strut mounting - Renewal	72
3.1	Tools	72
3.2	Procedure	72
4	Front longitudinal member - Partial renewal	78
4.1	Tools	78
4.2	Procedure	78
5	Front longitudinal member - Renewal	84
5.1	Tools	84
5.2	Procedure	84
6	Longitudinal member reinforcement (front) - Renewal	93
6.1	Tools	93
6.2	Procedure	93
51 - Body - centre		97
1	Permitted separating cuts on complete side panel	97
2	Roof - Renewal	99
2.1	Tools	99
2.2	Procedure	99
3	Roof - Renewal (version with tilting sunroof)	110
3.1	Tools	110
3.2	Procedure	110
4	Roof - Renewal (Sportback)	118
4.1	Tools	118
4.2	Procedure	119
5	Roof side member - Renewal	133
5.1	Tools	133
5.2	Procedure	133
6	Roof side member - foam-filling (Sportback)	137
6.1	Tools	137
6.2	Procedure	137
7	Roof side member - foam-filling	143
8	Roof cross member (front) - Renewal	154
8.1	Tools	154
8.2	Procedure	154
9	Rear roof frame - Renewal	157
9.1	Tools	157
9.2	Procedure	157
10	Rear roof cross member - Renewal (Sportback)	160
10.1	Tools	160
10.2	Procedure	160
11	A-pillar - Renewal (Coupé and Sportback identical)	165
11.1	Tools	165
11.2	Procedure	165
12	Inner A-pillar - Renewal (Coupé and Sportback identical)	172
12.1	Tools	172
12.2	Procedure	172
13	Outer B-pillar - Renewal (Sportback)	176
13.1	Tools	176
13.2	Procedure	176
14	Inner B-pillar - Renewal (Coupé)	181
14.1	Tools	181
14.2	Procedure	181

15	Inner B-pillar - Partial renewal (Coupé)	187
15.1	Tools	187
15.2	Procedure	187
16	Inner B-pillar - Partial renewal (Sportback)	193
16.1	Tools	193
16.2	Procedure	194
17	Outer side member - Renewal (Sportback)	205
17.1	Tools	205
17.2	Procedure	205
18	Inner side member - Renewal (Coupé and Sportback identical)	210
18.1	Tools	210
18.2	Procedure	210
19	Inner side member - Partial renewal (Coupé and Sportback identical)	218
19.1	Tools	218
19.2	Procedure	218
20	Inner side member reinforcement - Renewal (Coupé and Sportback identical)	223
20.1	Tools	223
20.2	Procedure	223
53 - Body - rear		228
1	Permitted separating cuts on complete side panel	228
2	Upper cross panel - Renewal	230
2.1	Tools	230
2.2	Procedure	230
3	Upper cross panel - Renewal (Sportback)	233
3.1	Tools	233
3.2	Procedure	234
4	Rear cross panel - Renewal (Coupé)	238
4.1	Tools	238
4.2	Procedure	238
5	Rear cross panel - Renewal (Sportback)	241
5.1	Tools	241
5.2	Procedure	241
6	Inner cross panel - Renewal (Coupé and Sportback identical)	245
6.1	Tools	245
6.2	Procedure	245
7	Tail light mounting - Renewal (Coupé and Sportback identical)	248
7.1	Tools	248
7.2	Procedure	248
8	Rear longitudinal member - Partial renewal (Coupé and Sportback identical)	251
8.1	Tools	251
8.2	Procedure	251
9	Rear longitudinal member - Renewal (Coupé and Sportback identical)	256
9.1	Tools	256
9.2	Procedure	256
10	Side panel - Renewal (Coupé)	263
10.1	Tools	263
10.2	Procedure	263
11	Side panel - Renewal (Sportback)	273
11.1	Tools	273
11.2	Procedure	274
12	Rear wheel housing - Renewal (Coupé and Sportback identical)	282
12.1	Tools	282

12.2	Procedure	282
13	Spare wheel well - Renewal (Coupé and Sportback identical)	287
13.1	Tools	287
13.2	Procedure	287