



Contents

00 - Materials	1
1 Materials for general body repairs	1
1.1 Materials for general body repairs	1
55 - Bonnet, Flaps	5
1 Tailgate-Exploded view	5
1.1 Tailgate-Exploded view	5
2 Removing tailgate	8
2.1 Removing tailgate	8
2.2 Tailgate adjustment operations	8
57 - Front doors/Door components/Central locking system	10
1 Front door-Exploded view	10
1.1 Front door-Exploded view	10
2 Adjustment work on front doors	17
2.1 Adjustment work on front doors	17
2.2 Adjusting door at front	17
2.3 Adjusting striker plate	18
3 Central locking system for cab doors-Exploded view	19
3.1 Central locking system for cab doors-Exploded view	19
3.2 Removing central, locking system motor for cab doors	20
4 Central locking system for sliding door-Exploded view	23
4.1 Central locking system for sliding door-Exploded view	23
4.2 Removing central locking system motor for sliding door	23
5 Central locking system for tailgate-Exploded view	24
5.1 Central locking system for tailgate-Exploded view	24
5.2 Removing central locking system motor for tailgate	25
6 Installing carrier plate for central locking system motor in replacement tailgate	26
6.1 Installing carrier plate for central locking system motor in replacement tailgate	26
6.2 Replacement tailgate	26
7 Removing and installing electric window lifter	27
7.1 Removing and installing electric window lifter	27
58 - Rear doors/Door components	31
1 Removing and installing sliding door cover	31
1.1 Removing and installing sliding door cover	31
1.2 Right hand rear side panel change	32
2 Removing and installing sliding door(From Model Year 1980 to Model Year 1984)	33
2.1 Removing and installing sliding door(From Model Year 1980 to Model Year 1984)	33
2.2 Adjusting the sliding door (From Model Year 1980 to Model Year 1984)	34
3 Remote control lock (sliding door)-Exploded view (From Model Year 1980 to Model Year 1984)	38
3.1 Remote control lock (sliding door)-Exploded view (From Model Year 1980 to Model Year 1984)	38
3.2 Remote control lock (sliding door) (Model Year 1980 to Model Year 1984)	41
3.3 Removing and installing central lock (sliding door) (From Model Year 1980 to Model Year 1984)	42
3.4 Positioning the cable pad and guide plug (sliding door) (From Model Year 1980 to Model Year 1984)	43
3.5 Adjusting sliding door Bowden cable (From Model Year 1980 to Model Year 1984)	43
4 Sliding door hinge link-Exploded view (From Model Year 1980 to Model Year 1984)	45
4.1 Sliding door hinge link-Exploded view (From Model Year 1980 to Model Year 1984)	45



4.2	Removing and installing sliding door hinge link (From Model Year 1980 to Model Year 1984)	48
5	Sliding door-Exploded view (From Model Year 1985 onwards)	49
5.1	Sliding door-Exploded view (From Model Year 1985 onwards)	49
5.2	Removing and installing sliding door (From Model Year 1985 onwards)	54
5.3	Adjustment operations on sliding door (From Model Year 1985 onwards)	56
6	Remote control lock for sliding door-Exploded view (From Model Year 1985 onwards)	62
6.1	Remote control lock for sliding door-Exploded view (From Model Year 1985 onwards)	62
6.2	Removing remote control lock for sliding door (From Model Year 1985 onwards)	65
6.3	Removing and installing central lock for sliding door (From Model Year 1985 onwards)	66
7	Sliding door hinge link-Exploded view (From Model Year 1985 onwards)	67
7.1	Sliding door hinge link-Exploded view (From Model Year 1985 onwards)	67
7.2	Renewing hinge link parts subject to wear (From Model Year 1985 onwards)	69
7.3	Adjustment operations on sliding door of high-roofed vehicles (From Model Year 1985 onwards)	69
7.4	Installing sliding door outer handle with M 145 (security lock cylinder)	71
60 - Sliding/tilting roof		72
1	Removing and installing sliding roof panel	72
1.1	Removing and installing sliding roof panel	72
2	Removing panel trim	73
2.1	Removing panel trim	73
3	Adjustment operations on sliding roof	75
3.1	Adjustment operations on sliding roof	75
3.2	Height adjustment	75
3.3	Adjusting the guide	76
3.4	Parallel adjustment	76
4	Cleaning water drain pipes from sliding roof	78
4.1	Cleaning water drain pipes from sliding roof	78
4.2	Removing rear water drain pipe	79
61 - Convertible top, Hardtop, Canopy		80
1	Service installation of canopy frame and canopy	80
1.1	Service installation of canopy frame and canopy	80
63 - Bumpers		84
1	Front bumpers-Exploded view	84
1.1	Front bumpers-Exploded view	84
1.2	Removing and installing front bumper	86
2	Rear bumper - Exploded view	87
2.1	Rear bumper - Exploded view	87
2.2	Removing and installing rear bumper with bracket	89
3	Rear bumper on caravelle carat-Exploded view	90
3.1	Rear bumper on caravelle carat-Exploded view	90
3.2	Removing and installing rear bumper for caravelle carat	92
4	Removing front bumper on caravelle carat	92
4.1	Removing front bumper on caravelle carat	92
64 - Glazing		94
1	Installing through-flow exit vent	94
1.1	Installing through-flow exit vent	94
1.2	Installing wind noise package	94
66 - Exterior equipment		97
1	Service installation of an automatic step with mudflap	97



1.1	Service installation of an automatic step with mudflap	97
2	Front spoiler on caravelle carat-Exploded view	101
2.1	Front spoiler on caravelle carat-Exploded view	101
2.2	Removing front spoiler on caravelle carat	102
2.3	Service installation of front spoiler on caravelle carat	102
3	Protective side panels on caravelle carat-Exploded view	103
3.1	Protective side panels on caravelle carat-Exploded view	103
3.2	Removing protective side panels on caravelle carat	105
4	Installing retainers for protective side panels on caravelle carat	106
4.1	Installing retainers for protective side panels on caravelle carat	106
5	Glass for electrically adjustable and heated outer rearview mirror-Exploded view	109
5.1	Glass for electrically adjustable and heated outer rearview mirror-Exploded view	109
5.2	Glass for electrically adjustable and heated outer rear-view mirror - Removing and installing	110
6	Mounting brackets for fog light and horn	110
6.1	Mounting brackets for fog light and horn	110
68	- Interior equipment	112
1	Load compartment cover-Exploded view	112
1.1	Load compartment cover-Exploded view	112
2	Retrofitting load compartment cover	113
2.1	Retrofitting load compartment cover	113
3	Trim panels for roof frame, window strips and pillars on caravelle carat-Exploded view	115
3.1	Trim panels for roof frame, window strips and pillars on caravelle carat-Exploded view	115
3.2	Removing and installing trim panels for roof frame, window strips and pillars on caravelle carat	117
70	- Trim/Insulation	123
1	Removing and installing trim panels for front doors	123
1.1	Removing and installing trim panels for front doors	123
1.2	Protective foil for front door trim	125
2	Trim for sliding door-Exploded view (From Model Year 1985 onwards)	126
2.1	Trim for sliding door-Exploded view (From Model Year 1985 onwards)	126
3	Removing instrument panel	127
3.1	Removing instrument panel	127
4	Removing and installing headlining for caravelle carat	130
4.1	Removing and installing headlining for caravelle carat	130
72	- Seat frames	132
1	Removing driver's Seat	132
1.1	Removing driver's Seat	132
1.2	Removing and installing driver's Seat backrest (From Model Year 1980 to Model Year 1984)	132
1.3	Removing driver's Seat backrest (From Model Year 1985 onwards)	133
2	Folding armrest for seats-Exploded view	134
2.1	Folding armrest for seats-Exploded view	134
2.2	Removing folding armrest for Seat	134
3	Adjustable armrest for Seat-Exploded view	135
3.1	Adjustable armrest for Seat-Exploded view	135
3.2	Removing adjustable armrest for Seat	136