



Contents

01 - Self-diagnosis, Electrical check	1
1 Self-diagnosis function	1
1.1 Self-diagnosis function	1
1.2 Technical data of self-diagnosis	3
1.3 Self-diagnosis - Guide	3
2 Locations of electrical/electronic components	4
2.1 Locations of electrical/electronic components	4
3 Performing self-diagnosis	17
3.1 Performing self-diagnosis	17
3.2 Connecting fault reader V.A.G 1551 and selecting functions	18
3.3 List of selectable functions	20
3.4 Interrogating fault memory	20
3.5 Fault table	21
3.6 Erasing fault memory	26
3.7 Initiating basic setting	27
3.8 Read measured value block	28
3.9 Test table	30
4 Gearbox: Electrical check	39
4.1 Gearbox: Electrical check	39
4.2 Electrical check	40
4.3 Test table	42
5 Definitions	48
5.1 Definitions	48