



## Contents

<b>01 - Self diagnosis</b> .....	<b>1</b>
<b>1 Self-diagnosis</b> .....	<b>1</b>
1.1 Self-diagnosis .....	1
1.2 Tools .....	1
1.3 Connecting fault reader .....	2
<b>2 Self-diagnosis of airbag/belt tensioner systems</b> .....	<b>3</b>
2.1 Self-diagnosis of airbag/belt tensioner systems .....	3
2.2 Function .....	3
2.3 Carrying out and checking adaptation of control unit .....	13

