



Contents

01 - Self-diagnosis	1
1 Vehicle diagnosis, testing and information systems	1
1.1 Connecting vehicle diagnosis, testing and information system VAS 5051A	2
2 Immobilizer self-diagnosis	4
2.1 Performing immobilizer self-diagnosis	5
2.2 Fault table	9
2.3 Measured value blocks	11
2.4 Coding immobilizer control unit J362	17
3 Guided functions of immobilizer, vehicles up to 05.00	20
3.1 Observe additional information and prerequisites for "online request with GeKo-VW"	20
3.2 Online system test	21
3.3 Adaption of ignition keys	21
3.4 Adaption when changing engine control unit	22
3.5 Adapting immobilizer	22
4 Guided fault finding / Guided functions of immobilizer, vehicles from 06.00	23
4.1 Observe additional information and prerequisites for "online request with GeKo-VW"	23
4.2 Online system test	24
4.3 Adaption of ignition keys	25
4.4 Adaption when changing engine control unit	25
4.5 Adaption when changing immobilizer	26
5 Self-diagnosis of dash panel insert ▶ 05.00	27
5.1 Locations for dash panel insert senders and sensors	27
5.2 Performing self-diagnosis of dash panel insert	30
5.3 Final control diagnosis	34
5.4 Coding control unit	37
5.5 Reading data block	38
5.6 Adaption (overview)	40
5.7 Adapting service interval data when changing the dash panel insert	41
5.8 Resetting service interval display	43
5.9 Adapting distance travelled display	45
5.10 Checking fuel gauge (adaption)	46
5.11 Adapting units of measurement displayed in dash panel insert	49
6 Dash panel self-diagnosis for vehicles 06.00 ▶	51
7 Data bus diagnostic interface	52
8 Gas discharge headlight and automatic headlight range control self-diagnosis 06.00 ▶	53
9 Parking aid self-diagnosis 06.00 ▶	54