



Contents

00 - Technical data	1
1 Vehicle identification data	1
1.1 Vehicle identification number	1
1.2 Identification plate	1
1.3 Vehicle data sticker	1
2 Body dimensions	2
2.1 Body - front	2
2.2 Body - centre	6
2.3 Body - rear	10
2.4 Floor group	12
3 Body panel gaps/shut lines	14
3.1 Body - front	14
3.2 Body - centre	15
3.3 Body - rear	16
4 Straightening jig	17
5 Galvanized body parts	24
50 - Body - front	25
1 Renewing engine bracket	25
1.1 Removing	25
2 Renewing gearbox bracket ▶ 05.00	27
2.1 Removing	27
3 Renewing gearbox bracket 06.00 ▶	29
3.1 Removing	29
4 Renewing support ▶ 05.00	31
4.1 Removing	31
5 Renewing support 06.00 ▶	33
5.1 Removing	33
6 Renewing end plate 06.00 ▶	35
6.1 Removing	35
7 Renewing upper wheel housing longitudinal member ▶ 05.00	37
7.1 Removing	37
8 Renewing upper wheel housing longitudinal member 06.00 ▶	39
8.1 Removing	39
9 Renewing front wheel housing - partial renewal ▶ 05.00	41
9.1 Removing	41
10 Renewing front wheel housing - partial renewal 06.00 ▶	44
10.1 Removing	44
11 Renewing front part of longitudinal member - partial renewal	47
11.1 Removing	47
51 - Body - centre	51
1 Renewing roof	51
1.1 Removing	51
2 Renewing front roof cross member	53
2.1 Removing	53
3 Renewing roof reinforcement	55
3.1 Removing	55
3.2 Installing	56
4 Renewing rear roof cross member	59



4.1	Removing	59
5	Renewing outer side panel - partial renewal	61
5.1	Removing	61
6	Renewing outer side panel - partial renewal	63
6.1	Removing	63
7	Renewing inner side panel	66
7.1	Removing	66
8	Renewing A-pillar- partial renewal	69
8.1	Removing	70
9	Renewing B-pillar- partial renewal	76
9.1	Removing	76
10	Renewing outer side member	80
10.1	Removing	80
11	Renewing inner side member - partial renewal	82
11.1	Removing	82
12	Renewing floor panel - partial renewal	84
12.1	Removing	84
53 - Body - rear		87
1	Renewing rear lock carrier	87
1.1	Removing	87
2	Renewing tail light mounting - partial renewal ▶ 05.00	89
2.1	Removing	89
3	Renewing tail light mounting - partial renewal 06.00 ▶	92
3.1	Removing	92
4	Renewing rear cross member - partial renewal	94
4.1	Removing	94
5	Renewing luggage compartment floor, partial renewal	97
5.1	Removing	97
6	Renewing bumper bracket	99
6.1	Removing	99
7	Renewing rear cross panel	101
7.1	Removing	101
8	Renewing rear longitudinal member - partial renewal	103
8.1	Includes: rear shock absorber mounting and extension arm	103
9	Renewing side panel - partial renewal ▶ 05.00	106
9.1	Removing	106
10	Renewing side panel - partial renewal 06.00 ▶	109
10.1	Removing	109
11	Renewing rear wheel housing	112
11.1	Removing	112
12	Renewing cross member	115
12.1	Removing	115