



Contents

01 - Self-diagnosis	1
1 Self-diagnosis of Climatronic, vehicles: ▶ 05.00	1
1.1 Connecting vehicle diagnosis, testing and information system VAS 5051	1
1.2 Function	2
1.3 Overview - available functions	2
1.4 Read control unit version	3
1.5 Reading and clearing fault memory	3
1.6 Fault table	4
1.7 Final control diagnosis	10
1.8 Coding Climatronic control unit J255	12
1.9 Read measured value block	13
80 - Heating	17
1 Repairing heating system	17
1.1 Removing and installing vents	18
1.2 Removing and installing air duct	19
1.3 Removing and installing dust and pollen filter	20
1.4 Checking air extraction	21
2 Removing and installing heater unit	22
3 Dismantling and assembling heated air and fresh air controls	25
4 Dismantling and assembling heater unit	26
5 Vacuum hose connection diagram	27
6 Repairing heating and ventilation for passenger compartment	28
87 - Air conditioning system	29
1 Notes on repair work to vehicles with air conditioning and on handling refrigerant	29
2 Air conditioning system with manual controls, vehicles ▶ 05.00	30
2.1 Repairing air conditioning and heating - passenger compartment	30
2.2 Dismantling and assembling air conditioning system controls	32
2.3 Repairing air conditioning and heating - engine compartment	33
3 Air conditioning system with manual controls, vehicles 06.00 ▶	36
3.1 Repairing air conditioning and heating - passenger compartment	36
3.2 Removing vents	38
3.3 Removing and installing glove box cooling	40
3.4 Removing and installing air conditioning system control unit J301	40
3.5 Dismantling and assembling air conditioning system control unit J301	41
3.6 Repairing air conditioning system with manual controls - additional heat exchanger	42
3.7 Repairing air conditioning and heating - engine compartment	45
4 Climatronic air conditioning system with automatic regulation, vehicles ▶ 05.00	48
4.1 Operation and function of displays and control buttons on Climatronic control unit J255	49
4.2 Repairing Climatronic - dash panel area	50
4.3 Removing and installing operating and display unit for Climatronic air conditioning system E87 with Climatronic control unit J255	54
4.4 Repairing Climatronic - additional heat exchanger	55
4.5 Repairing Climatronic - 2nd evaporator	57
4.6 Repairing Climatronic - engine compartment	58
4.7 Checking excess pressure relief valve on air conditioner compressor	61
4.8 Coolant hose connection diagram	62
4.9 Vacuum hose connection diagram	64
5 Climatronic air conditioning system with automatic regulation, vehicles 06.00 ▶	65
5.1 Procedure for checking and adjusting components	65
5.2 Operation and function of displays and control buttons on Climatronic control unit J255	66



5.3	Repairing Climatronic - dash panel area	67
5.4	Removing and installing operating and display unit for Climatronic air conditioning system E87 with Climatronic control unit J255	73
5.5	Repairing Climatronic - additional heat exchanger	74
5.6	Repairing Climatronic - 2nd evaporator	76
5.7	Repairing Climatronic - engine compartment	77
5.8	Coolant hose connection diagram	80
6	Removing and installing air conditioner compressor and/or ancillary bracket	82
6.1	Engine code ADY	82
6.2	Engine codes AAA and AMY	84
6.3	Engine code AYL	86
6.4	Engine codes 1Z, AFN, AHU and AVG	88
6.5	Engine codes AJH, ATM and AWC	90
6.6	Engine codes ANU, AJM, ASZ, AUY, BRT, BTB, BVH and BVK	92
7	Repair work on refrigerant circuit which may be performed only in suitable workshops by specially trained mechanics	95
7.1	Repairing Sanden air conditioning system magnetic clutch N25 with air conditioner compressor removed	95
7.2	Running-in procedure for air conditioner compressor and temperature measurement	100
8	Repair work on refrigerant circuit which may be carried out only in suitable workshops by specially trained mechanics, vehicles > 05.00	102
8.1	Tools	103
8.2	Repairing components in refrigerant circuit	104
8.3	Overview - components in the refrigerant circuits for front and rear seats	105
8.4	Removing evacuating and charging valve, low-pressure side	111
8.5	Removing evacuation and charging valve, high-pressure side	113
8.6	Checking excess pressure relief valve on air conditioner compressor	115
8.7	Repairing refrigerant circuit for rear seats	115
8.8	Removing expansion valve	117
8.9	Removing and installing condenser	119
8.10	Removing and installing receiver with dryer	120
8.11	Removing and installing air conditioner compressor	121
8.12	Removing and installing heater and air conditioning unit	123
8.13	Dismantling and assembling heater and air conditioning unit for front and rear seats	125
9	Repair work on refrigerant circuit which may be carried out only in suitable workshops by specially trained mechanics, vehicles 06.00 >	129
9.1	Repairing components in refrigerant circuit	131
9.2	Overview - components in the refrigerant circuits for front and rear seats	131
9.3	Removing expansion valve	140
9.4	Removing and installing condenser	142
9.5	2nd evaporator housing for rear seats	144
9.6	Remove dryer cartridge in receiver	145
9.7	Removing and installing air conditioner compressor	148
9.8	Removing and installing heater and air conditioning unit	150
9.9	Dismantling and assembling heater and air conditioning unit for front and rear seats	152
10	Capacities	154
10.1	Refrigerant R134a	154
10.2	Refrigerant oil	154
10.3	Oil distribution	155