



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Connecting fault reader V.A.G 1551 and selecting engine electronics control unit	3
2 Fault memory	5
2.1 Fault memory	5
2.2 Interrogating and erasing fault memory	5
3 Fault table, fault codes 00515...01262	7
3.1 Fault table, fault codes 00515...01262	7
4 Fault table, fault codes 16486...18034	13
4.1 Fault table, fault codes 16486...18034	13
5 Final control diagnosis	23
5.1 Final control diagnosis	23
5.2 Performing final control diagnosis	23
6 Measured value blocks	31
6.1 Measured value blocks	31
6.2 Safety precautions	31
6.3 Read measured value block	31
7 Evaluating measured value blocks, display groups 0...13	32
7.1 Evaluating measured value blocks, display groups 0...13	32
8 Evaluating measured value blocks, display groups 14...99	43
8.1 Evaluating measured value blocks, display groups 14...99	43
24 - Mixture preparation, Injection	48
1 Servicing injection system	48
1.1 Servicing injection system	48
1.2 Fitting locations overview	48
1.3 General notes on injection	51
1.4 Removing and installing parts of the injection system	52
1.5 Dismantling and assembling air cleaner	59
1.6 Dismantling and assembling fuel rail with injectors	60
1.7 Safety precautions	62
1.8 Rules for cleanliness	63
1.9 Technical data	63
2 Checking components	64
2.1 Checking components	64
2.2 Checking Lambda probe heating	64
2.3 Checking air mass meter	66
2.4 Checking throttle valve control part	68
2.5 Checking coolant temperature sender	75
2.6 Checking intake air temperature sender	79
2.7 Checking engine speed sender	82
2.8 Testing altitude sender	83
2.9 Checking injectors	85
2.10 Checking fuel pressure regulator and holding pressure	91
2.11 Checking intake air system for leaks (unmetered air)	94
3 Checking functions	95
3.1 Checking functions	95
3.2 Idling check	95
3.3 Adapting idling speed	97



3.4	Checking Lambda control	98
3.5	Checking engine operating mode	101
3.6	Checking driving characteristics after a cold start	103
4	Engine control unit	104
4.1	Engine control unit	104
4.2	Checking control unit voltage supply	104
4.3	Procedure after voltage supply open circuit	106
4.4	Replacing engine control unit	106
4.5	Coding engine control unit	107
4.6	Coding variations of engine control unit	108
4.7	Matching engine control unit to throttle valve control part	108
4.8	Matching engine control unit to electronic immobilizer	110
5	Checking additional signals	111
5.1	Checking additional signals	111
5.2	Checking speed signal	111
5.3	Checking signal from/to air conditioning system	112
5.4	Checking ignition retardation during gear selection	114
5.5	Checking driving range signal	115
28	- Ignition system	117
1	Servicing ignition system	117
1.1	Servicing ignition system	117
1.2	General notes to ignition system	117
1.3	Removing and installing parts of the ignition system	118
1.4	Safety precautions	121
1.5	Test data, spark plugs	121
1.6	Checking Hall sender	121
1.7	Checking ignition coils with output stage	123
1.8	Checking knock sensor	127