



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of the exhaust gas warning lamp	2
1.5 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	3
1.6 Connecting fault reader	4
2 Fault memory	7
2.1 Fault memory	7
2.2 Automatic test sequence	7
2.3 Interrogating and erasing fault memory	8
3 Fault table: SAE P0 codes	9
3.1 Fault table: SAE P0 codes	9
4 Fault table: SAE P1 codes	15
4.1 Fault table: SAE P1 codes	15
5 Readiness code	24
5.1 Readiness code	24
5.2 Reading readiness code	24
5.3 Generating readiness code	25
6 Final control diagnosis	32
6.1 Final control diagnosis	32
6.2 Performing final control diagnosis	32
7 Measured value blocks	42
7.1 Measured value blocks	42
7.2 Safety precautions	42
7.3 Read measured value block	42
8 Evaluating measured value blocks, display groups 0...9 -Basic functions-	43
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	43
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	47
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	47
10 Evaluating measured value blocks, display groups 30...49, 99, 107 -Lambda regulation-	49
10.1 Evaluating measured value blocks, display groups 30...49, 99, 107 -Lambda regulation-	49
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	54
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	54
12 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	58
12.1 Evaluating measured value blocks, display groups 70...79 -Reducing emissions-	58
13 Evaluating measured value blocks, display groups 110...119 -Charge pressure control-	59
13.1 Evaluating measured value blocks, display groups 110...119 -Charge pressure control-	59
14 Evaluating measured value blocks, display groups 120...129 -Communication-	61
14.1 Evaluating measured value blocks, display groups 120...129 -Communication-	61
24 - Mixture preparation, Injection	63
1 Servicing injection system	63
1.1 Servicing injection system	63
1.2 Fitting locations overview	63
1.3 General notes on injection	67
1.4 Removing and installing parts of the injection system	67
1.5 Dismantling and assembling air cleaner	73
1.6 Dismantling and assembling fuel rail with injectors	74



1.7	Safety precautions	75
1.8	Rules for cleanliness	76
1.9	Technical data	77
2	Checking components	77
2.1	Checking components	77
2.2	Checking Lambda probe heating for Lambda probe before catalyst	77
2.3	Checking Lambda probe heating for Lambda probe after catalyst	80
2.4	Checking air mass meter	83
2.5	Checking throttle valve control part	86
2.6	Checking coolant temperature sender	89
2.7	Checking intake air temperature sender	93
2.8	Checking engine speed sender	96
2.9	Checking injectors	98
2.10	Checking fuel pressure regulator and holding pressure	104
2.11	Checking intake air system for leaks (unmetered air)	108
3	Checking functions	109
3.1	Checking functions	109
3.2	Idling check	109
3.3	Checking Lambda probe and Lambda regulation before catalyst	111
3.4	Checking Lambda probe and Lambda regulation after catalyst	113
3.5	Checking Lambda probe ageing, Lambda probe before catalyst	117
3.6	Checking Lambda probe ageing, Lambda probe after catalyst	118
3.7	Checking engine operating mode	119
4	Engine control unit	121
4.1	Engine control unit	121
4.2	Checking control unit voltage supply	121
4.3	Procedure after voltage supply open circuit	123
4.4	Replacing engine control unit	123
4.5	Adapting engine control unit to throttle valve control part and EGR valve	124
4.6	Learning kick-down point	126
4.7	Checking data bus matching resistor	127
5	Checking additional signals	128
5.1	Checking additional signals	128
5.2	Checking speed signal	128
5.3	Checking signal from/to air conditioning system	129
5.4	Checking signal from clutch pedal switch	131
5.5	Checking signal from brake light switch and brake pedal switch	133
5.6	Checking driving range signal	135
28	- Ignition system	137
1	Servicing ignition system	137
1.1	Servicing ignition system	137
1.2	General notes on ignition system	137
1.3	Removing and installing parts of the ignition system	137
1.4	Safety precautions	139
1.5	Test data, spark plugs	140
1.6	Checking Hall sender	140
1.7	Checking ignition coils with output stage	142
1.8	Checking knock sensor	145
1.9	Check misfiring recognition	147