



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	1
1.4 Significance of exhaust emissions warning lamp	2
1.5 Technical data of self-diagnosis	3
1.6 Connecting fault reader	4
2 Fault memory	7
2.1 Fault memory	7
2.2 Interrogating and erasing fault memory	7
3 Fault table: from V.A.G code 16396 / SAE P0 and P2 codes	9
3.1 Fault table: from V.A.G code 16396 / SAE P0 and P2 codes	9
4 Fault table: from V.A.G code 17510 / SAE P1 and P3 codes	15
4.1 Fault table: from V.A.G code 17510 / SAE P1 and P3 codes	15
5 Readiness code	20
5.1 Readiness code	20
5.2 Reading readiness code	21
5.3 Generating readiness code	22
6 Final control diagnosis	34
6.1 Final control diagnosis	34
6.2 Performing final control diagnosis	34
7 Measured value blocks	50
7.1 Measured value blocks	50
7.2 Safety precautions	50
7.3 Read measured value block	50
8 Evaluating measured value blocks, display groups 0...6 -Basic functions-	51
8.1 Evaluating measured value blocks, display groups 0...6 -Basic functions-	51
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	55
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	55
10 Evaluating measured value blocks, display grps. 30...33, 99 -Lambda regulation-	57
10.1 Evaluating measured value blocks, display grps. 30...33, 99 -Lambda regulation-	57
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	62
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	62
12 Evaluating measured block values, display groups 90...95 -Performance improvement-	66
12.1 Evaluating measured block values, display groups 90...95 -Performance improvement-	66
13 Evaluating measured value block, display group 125 -Communication-	67
13.1 Evaluating measured value block, display group 125 -Communication-	67
24 - Mixture preparation, Injection	68
1 Servicing injection system	68
1.1 Servicing injection system	68
1.2 Fitting locations overview	68
1.3 General notes on injection	75
1.4 Removing and installing parts of the injection system	76
1.5 Dismantling and assembling intake manifold	86
1.6 Dismantling and assembling fuel rail	90
1.7 Dismantling and assembling air cleaner	92
1.8 Dismantling and assembling intake manifold	94
1.9 Safety precautions	97
1.10 Rules for cleanliness	98



1.11	Technical data	98
2	Checking components	99
2.1	Checking components	99
2.2	Checking Lambda probe heating for Lambda probe before catalyst	99
2.3	Checking Lambda probe heating for Lambda probe after catalyst	102
2.4	Checking air mass meter	106
2.5	Checking throttle valve control part	109
2.6	Checking coolant temperature sender	113
2.7	Checking intake air temperature sender	118
2.8	Checking engine speed sender	123
2.9	Checking injectors	125
2.10	Checking fuel pressure regulator and holding pressure	131
2.11	Checking intake manifold change-over	134
2.12	Checking intake air system for leaks (unmetered air)	136
3	Checking functions	137
3.1	Checking functions	137
3.2	Idling check	137
3.3	Adapting idling speed	139
3.4	Checking Lambda probe and Lambda regulation before catalyst	140
3.5	Checking Lambda probe and Lambda regulation after catalyst	143
3.6	Checking Lambda probe ageing of Lambda probe before catalyst	146
3.7	Checking Lambda probe ageing Lambda probe after catalyst (adaption)	148
3.8	Checking engine operating mode	149
4	Engine control unit	151
4.1	Engine control unit	151
4.2	Checking control unit voltage supply	151
4.3	Procedure after voltage supply open circuit	153
4.4	Erasing values learnt by engine electronics control unit	153
4.5	Replacing engine control unit	154
4.6	Adapting engine control unit to throttle valve control part	155
4.7	Learning kick-down point	157
5	Checking additional signals	158
5.1	Checking additional signals	158
5.2	Checking speed signal	158
5.3	Checking signal from/to air conditioner	160
5.4	Checking signal from clutch pedal switch	162
5.5	Checking signal from brake light switch and brake pedal switch	164
5.6	Checking driving range signal	167
5.7	Checking data bus	168
28	- Ignition system	170
1	Servicing ignition system	170
1.1	Servicing ignition system	170
1.2	General notes on ignition system	170
1.3	Removing and installing parts of the ignition system	171
1.4	Safety precautions	176
1.5	Test data, spark plugs	177
1.6	Checking Hall sender	178
1.7	Checking ignition coils with output stage	181
1.8	Checking knock sensor	184
1.9	Check misfiring recognition	188