



Contents

01 - Self-diagnosis	1
1 General to self-diagnosis	1
1.1 General to self-diagnosis	1
1.2 Features of self-diagnosis	1
1.3 Technical data of self-diagnosis	1
1.4 Significance of the exhaust gas warning lamp	2
1.5 Significance of EPC warning lamp (fault lamp for electronic accelerator) in dash panel insert	3
1.6 Connecting fault reader	4
2 Fault memory	7
2.1 Fault memory	7
2.2 Automatic test sequence for interrogating all fault memories	7
2.3 Interrogating and erasing engine control unit fault memory	8
3 Fault table: SAE P0 and P2 codes	9
3.1 Fault table: SAE P0 and P2 codes	9
4 Fault table: SAE P1 and P3 codes	15
4.1 Fault table: SAE P1 and P3 codes	15
5 Readiness code	22
5.1 Readiness code	22
5.2 Reading readiness code	23
5.3 Generating readiness code	23
6 Final control diagnosis	30
6.1 Final control diagnosis	30
6.2 Performing final control diagnosis	30
7 Measured value blocks	40
7.1 Measured value blocks	40
7.2 Safety precautions	40
7.3 Read measured value block	41
8 Evaluating measured value blocks, display groups 0...9 -Basic functions-	42
8.1 Evaluating measured value blocks, display groups 0...9 -Basic functions-	42
9 Evaluating measured value blocks, display groups 10...29 -Ignition-	45
9.1 Evaluating measured value blocks, display groups 10...29 -Ignition-	45
10 Evaluating measured value blocks, display groups 30...49, 99 -Lambda regulation-	48
10.1 Evaluating measured value blocks, display groups 30...49, 99 -Lambda regulation-	48
11 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	53
11.1 Evaluating measured value blocks, display groups 50...69 -Speed regulation-	53
12 Evaluating measured value blocks, display groups 70...89 -Reducing emissions-	57
12.1 Evaluating measured value blocks, display groups 70...89 -Reducing emissions-	57
13 Evaluating measured value blocks, display groups 120...129 -Communication-	58
13.1 Evaluating measured value blocks, display groups 120...129 -Communication-	58
24 - Mixture preparation, Injection	60
1 Servicing injection system	60
1.1 Servicing injection system	60
1.2 Fitting locations overview	60
1.3 General notes on injection	68
1.4 Dismantling and assembling intake manifold - Upper part	69
1.5 Dismantling and assembling intake manifold - lower part	72
1.6 Dismantling and assembling air cleaner	74
1.7 Safety precautions	75
1.8 Rules for cleanliness	76
1.9 Technical data	76



2	Checking components	77
2.1	Checking components	77
2.2	Checking Lambda probe heating for Lambda probe before catalyst	77
2.3	Checking Lambda probe heating for Lambda probe after catalyst	80
2.4	Checking air mass meter	83
2.5	Checking throttle valve control part	86
2.6	Checking coolant temperature sender	90
2.7	Checking intake air temperature sender	94
2.8	Checking engine speed sender	99
2.9	Checking injectors	101
2.10	Checking fuel pressure regulator and holding pressure	107
2.11	Checking intake air system for leaks (unmetered air)	110
3	Checking functions	111
3.1	Checking functions	111
3.2	Idling check	111
3.3	Checking Lambda probe and Lambda regulation before catalyst	113
3.4	Checking Lambda probe and Lambda regulation after catalyst	116
3.5	Checking Lambda probe ageing, Lambda probe before catalyst	120
3.6	Checking engine operating mode	121
4	Engine control unit	122
4.1	Engine control unit	122
4.2	Checking control unit voltage supply	122
4.3	Replacing engine control unit	124
4.4	Adapting engine control unit to throttle valve control part and exhaust gas recirculation valve	126
4.5	Learning kick-down point	128
4.6	Checking matching resistor for data bus	129
5	Checking additional signals	130
5.1	Checking additional signals	130
5.2	Checking speed signal	130
5.3	Checking signal from/to air conditioning system	131
5.4	Checking signal from clutch pedal switch	132
5.5	Checking signal from brake light switch and brake pedal switch	134
5.6	Checking driving range signal	137
28	Ignition system	139
1	Servicing ignition system	139
1.1	Servicing ignition system	139
1.2	General notes on ignition system	139
1.3	Removing and installing parts of the ignition system	140
1.4	Safety precautions	143
1.5	Test data, spark plugs	143
1.6	Checking Hall sender	144
1.7	Checking ignition transformer	145
1.8	Checking knock sensor	149
1.9	Check misfiring recognition	151